Thank you for purchasing our

# Cresco 5 Fertilizer and Salt Spreader | Assembled



We're delighted to have you as a customer and are here to help! First off, let's get your product assembled!

# Table of Contents:


**1:** Assembling your Cresco 5 **2-3:** How to Use the Cresco 5

4: Warranty







# Assembling your Cresco 5




Locate the main unit. Inside the bag, you will find the crank handle.



To attach the crank handle, screw the crank handle onto the shaft by turning it in a clockwise direction.



To operate, the aperture is set on the gauge assembly as shown by locking the wing nut in the desired position on the 1 to 6 scale.



Once the desired application rate is set on the gauge, fill the bag with the fertiliser or seed material. Crank the handle at appoximately 1 revolution a second. At the point of walking forward, squeeze the lever up into the preset position and material will be evenly spread out infront as the impellor rotates. Once the area to be treated is covered, release the lever into the closed position and cease the cranking of the handle.

## How to use the Cresco 5

#### How to Apply Fertilizer to your lawn like a pro in four steps!

Step 1: Understanding the application rate and settings

**Step 2:** Preparing the Spreader

**Step 3:** Walking Patterns for the optimum application

#### Step 1: Understand the application rate and settings Application Rate Settings

Check the back of the fertilizer bag to find out the recommended G/m<sup>2</sup> and spreader application setting.



If the spreader setting is not on the back of the bag, please get in touch with your fertilizer bag provider.



### Step 2: Preparing the Spreader

Check the material to be applied is dry and free flowing to ensure it will flow freely. Make sure your application rate and spread pattern settings are correct, full stop.

Make sure the bag application hole is closed and then pour in your material.





WARNING \*\*Do not pour material in the hopper when the application hole is open as it can lead to spillages or leaks that can damage the area. Do not open the gauge until you are over the area you want to spread and are moving at a brisk walk\*\*\*

## How to use the Cresco 5

Step 3: Walking Patterns for the optimum application (For Fertilizer Only)


There are two methods of effective spreading, longitudinal fertilizer spreading and cross sectional fertilizer spreading.

When applying fertilizer please make sure you walk at approximately 3mph and keep the spreader in a stable position.

#### Single Pass Fertilizer Spreading

Use ½ the application rate suggested on the back of your fertilizer bag.


Cover the area as shown by passing over it in an up and down track as shown, taking into account the spread width of the material being applied.



#### **Cross Sectional Fertilizer Spreading**

Use ½ the application rate suggested on the back of your fertilizer bag

Cover the area as shown. Repeating by a second pass in the same manner going across the area as shown in the diagram.



If you are unable to find the required Cresco volume setting, please visit, www.crescospreaders.com

# 3-Year Limited Warranty

DMMP Ltd. warrants this product free of defects in original workmanship and materials for a period of 3 Years to the end user with the original dated purchase receipt.

If a manufacturing non-conformance is found, DMMP Ltd. will repair or replace the part(s) or product at it's discretion at no charge provided the failure is not the result of incorrect installation, mishandling, misuse, tampering, or normal wear and tear as determined by DMMP ltd.

DMMP Ltd. at its discretion may require that the part(s) or product be returned along with the original purchase receipt at owners' expense for examination and compliance with the terms of this warranty.

Do not return any product without first receiving authorization from DMMP Ltd. To seek remedy under this warranty, contact DMMP Ltd. at +44 (0)1455 825 400 or email us at info@ dmmp.co.uk and describe the nature of the manufacturing defect.

#### SPECIFIC LIMITATIONS:

This warranty covers only the part(s) or product; any labour charges associated with repair or replacement of nonconformances are specifically excluded.

Due to the corrosive nature of most fertilizers and ice melt products, DMMP Ltd makes no warranty against and specifically excludes part(s) or product degradation or failure due to corrosion or its effects.

To negate the effects of corrosive materials on your product, clean and dry your spreader or seeder thoroughly after each use. As a further preventative measure, coat all metal parts with a light oil or silicon spray.

# Other Cresco Products

Product / Season	Unique Selling Points	
Cresco 1 Code: CR001	Ergonomic arm-rest handle for easy holding	Large 2Kg Hopper
Cresco 5 Code: CR005	New heavy duty gearbox	Easy to use on/off system
Cresco 10SW Code: CR10SW	Cushioned on/off lever with solid rod linkage	Large moulded wheels
Cresco 20SW Code: CR20SW	Cushioned on/off lever with solid rod linkage	Pneumatic Wheels
Cresco SRS Code: CRSRS	Seed Plate Bag Included with 11 Seed Plates	Strong row marker mounting
Heavy Duty Snow Shovel Code: H464P	Powder coated steel tubed handle	Large comfortable ergonomic grip
Wide Snow Clearer Code: H611	Steel blade	Steel edge to increase cutting power and longevity
3 in 1 Foldable Snow Shovel Code: HZS212	Anodised aluminimum head	Teloscopic anodised aluminimum handle
Cresco Snow  Blaster Code: H595	Two grip design makes snow removal easy and minimises lifting and stooping	Wave ribbed design reinforces blade strength
Polar Tough Snow Plough Code: YH74900	Helps manage snow accumulation	Reduces labour costs compared to a shovel